

Tablas de calibración

Fertibites® 28-7-14

Esparcidora al Voleo (Grande)		
Scotts® Edgeguard DXL		
g/m2	kg/100 m ²	Calibración
20	1.8	6.5
30	2.8	7.5
40	3.7	8.5

Esparcidora al Voleo (Mini)		
Scotts® Edgeguard Mini		
g/m2	kg/100 m ²	Calibración
20	1.8	8
30	2.8	9
40	3.7	10

Esparcidora de Gravedad		
Scotts® AccuGreen 1000		
g/m2	kg/100 m ²	Calibración
20	1.8	9
30	2.8	11
40	3.7	14

Esparcidora Manual		
Scotts® Whirl		
g/m2	kg/100 m ²	Calibración
20	1.8	5

Fertibites® 14-21-7

Esparcidora al Voleo (Grande)		
Scotts® Edgeguard DXL		
g/m2	kg/100 m ²	Calibración
20	1.8	6
30	2.8	7
40	3.7	8
50	4.6	9

Esparcidora al Voleo (Mini)		
Scotts® Edgeguard Mini		
g/m2	kg/100 m ²	Calibración
20	1.8	7
30	2.8	8.5
40	3.7	12
50	4.6	14

Esparcidora de Gravedad		
Scotts® AccuGreen 1000		
g/m2	kg/100 m ²	Calibración
20	1.8	9
30	2.8	11
40	3.7	14

Esparcidora Manual		
Scotts® Whirl		
g/m2	kg/100 m ²	Calibración
20	1.8	5

Fertibites® 17-17-17

Esparcidora al Voleo (Grande)		
Scotts® Edgeguard DXL		
g/m2	kg/100 m ²	Calibración
20	1.8	6
30	2.8	7
40	3.7	8
50	4.6	9

Esparcidora al Voleo (Mini)		
Scotts® Edgeguard Mini		
g/m2	kg/100 m ²	Calibración
20	1.8	7
30	2.8	8.5
40	3.7	10
50	4.6	10.5

Esparcidora de Gravedad		
Scotts® AccuGreen 1000		
g/sq ft	kg/100 m ²	Calibración
20	1.8	9.5
30	2.8	11
40	3.7	12.5
50	5	14

Esparcidora Manual		
Scotts® Whirl		
g/sq ft	kg/100 m ²	Calibración
20	1.8	5